

PART # REMAN'D. CONSOLES**SOFTWARE**

98-01101

Rev.21

Mar. 24, 2008

95-75000	Console, Remanufactured, ARC-6000 (raw)		2.03
95-75023	Console, Remanufactured, ARC 6000 w/man.		2.03
95-75011	Console, Remanufactured, ARC Liquid (raw)		1.31a
95-75024	Console, Remanufactured, ARC Liquid w/man.		1.31a
95-75010	Console, Remanufactured, ARC, Melroe		1.20
95-75041	Console, Remanufactured, ARC-6000 CE , (Raw)		2.03
95-75042	Console, Remanufactured, ARC-6000 CE , w/man.		2.03
95-75009	Console, Remanufactured, TASC 6000	master	3.23
95-75026	Console, Remanufactured, TASC 6000 w/man.	master	3.23
95-75013	Console, Remanufactured, TASC 6100 (raw)	master	1.30
		fan	2.31
95-75031	Console, Remanufactured, TASC 6100 w/man.	master	1.30
		fan	2.31
95-75051	Console, Remanufactured, TASC 6100 CE (Raw)	master	1.30
		fan	2.31
95-75052	Console, Remanufactured, TASC 6100 CE, w/man.	master	1.30
		fan	2.31
95-75007	Console, Remanufactured, TASC 6200 Gran. (raw)	master	2.62
		L slave	2.35
95-75030	Console, Remanufactured., TASC 6200 Granular	master	2.62
		L slave	2.35
95-75049	Console, Remanufactured., TASC 6200 CE (Raw)	master	2.62
		Slave	2.35
95-75050	Console, Remanufactured, TASC 6200 CE, w/man.	master	2.62
		Slave	2.35
95-75012	Console, Remanufactured., TASC 6300 (raw)	master	3.23
		pump slave	3.05
95-75027	Console, Remanufactured, TASC 6300 w/man.	master	3.23
		pump slave	3.05
95-75047	Console, TASC 6300, CE, Raw	master	3.23
		Slave	3.05
95-75048	Console, TASC 6300 CE w/man.	master	3.23
		Slave	3.05
95-75008	Console, Remanufactured, TASC 6500 Gran. (raw)	master	2.62
		L slave	2.35
		pump slave	2.26
95-75029	Console, Remanufactured., TASC 6500 Gran.	master	2.62
		L slave	2.35
		pump slave	2.26
95-75045	Console, Remanufactured., TASC 6500 CE (Raw)	master	2.62
		L-Slave	2.35
		pump slave	2.26
95-75046	Console, Remanufactured, TASC 6500 CE, w/man.	master	2.62
		L-Slave	2.35
		pump slave	2.26

PART # REMAN'D. CONSOLES Cont'd SOFTWARE

95-75002	Console, Remanufactured, TASC 6600 (raw)	master	3.23
		pump slaves	3.05
95-75028	Console, Remanufactured, TASC 6600 w/man.	master	3.23
		pump slaves	3.05
95-75043	Console, Remanufactured, TASC 6600 CE, (Raw)	master	3.23
		Slave	3.05
95-75044	Console, Remanufactured, TASC 6600 CE, w/man.	master	3.23
		Slave	3.05
95-75001	Console, Remanufactured, Aglogix (raw)		1.03
95-75014	Console, Remanufactured, Aglogix w/man.		1.03
95-75032	Console, Remanufactured, Aglogix Injection		1.00
95-75004	Console, Remanufactured, ISC (raw)		4.3
95-75016	Console, Remanufactured, ISC w/ I/O manual		4.3
95-75003	Console, Remanufactured, FCI 4000 (raw)		4.3
95-75015	Console, Remanufactured, FCI 4000 w/ I/O manual		4.3
95-75005	Console, Remanufactured, CCI 7 Section (raw)		
95-75006	Console, CCI 5 Section (raw)		
95-75017	Console, Remanufactured, CCI 7 Sec. w/ I/O manual		
95-75018	Console, Remanufactured, CCI 5 Sec. w/ I/O manual		
95-75033	Console, ATC, 5 Boom, Raw		
95-75034	Console, ATC, 5 Boom, with Manual (As Shipped)		
95-75039	Console, L2K, Raw		
95-75040	Console, L2K, As Shipped		

PART # DATALINKS SOFTWARE

			as sold
405-0069-96	Interface Datalink '96 Version		1.00
406-4000	Datalink, AgLogix		1.00
78-05007	Datalink, Interface (98 Protocol)		5.00
78-05014	Datalink, BATTs (98 protocol)		5.00

PART # OTHER DEVICES SOFTWARE

			as sold
105-0026	Willmar Spinner		1.02
117-0012	Printer, TASC Datalogger		3.3
117-0013	Printer, TASC Datalogger, Roadside		3.4
405-0070	BATTs switchbox		4.3
405-0072	Auto-Tip-Control (pre 1998)		2.2
45-05012	Pump to Servo Interface (DMI)		1.02
45-05019	Dual Sensor Comparator (Ag-Chem)		1
45-10022	Opto-Sensor (DMI)		1
78-00011	ATC Batts		3.00
78-05006	Master Control Unit		1.03
78-05008	Stepper Motor Drive (New Leader, MKIV)		1.02
90-01006	Auto-Tip-Control (1998)		1.00
78-05032	Interface, Mark IV Driver		1.02

PART # LH Agro Devices**SOFTWARE**

as purch'd as sold

75-30000	M-1 Console, as purchased and included with kit 90-02032	1012.01	1012.01
----------	--	---------	---------

** Software custom developed for Mid-Tech by LH Agro.

PART # LEGACY PRODUCTS**SOFTWARE**

78-50059	Legacy 2000 SRAM Card		01.00V
78-08009	PCM, with L2K		01.00S
78-08007	PSM, with L2K		01.00L
78-08008	SSM, with L2K		1.03
78-08016	PCM, with L6K		3.14
78-08017	PSM, with L6K		3.14
78-08018	SSM, with L6K		3.14
78-08028	PSM, with L6K, RMS		3.01
78-08029	SSM with L6K, RMS		3.01
78-08030	PCM with L6K, RMS		3.01
78-08025	DCM Dual Control Module		3.14
78-08050	Dual Control Module, RMS		3.13
75-05006	Console, L6K Stand Alone		1.07
75-05007	Console, L6K Color, CAN Version		3.14
75-05003	Console, L6K, CAN Version		3.10
75-05004	Console, L6K Color Version - Generic		3.14
75-05012	Console, L6K Color w/RMS Ext.		2.00
75-05015	Console, L6K CB, w/MV		3.14
75-05017	Console, L6K Color, RMS-CB		2.01
75-05009	Console, L6K Color Trimble Autopilot		2.10
75-05010	Console, L6K SA w/Fieldpilot		2.10
75-05020	Console, L6K RMS Gen II		2.50

PART # Nav Products**SOFTWARE**

98-50000	Fieldware	2.00b
98-50004	Fieldware Suite w/lightbar	2.00b
98-50007	RMS, For MC-1000	1.00b
98-50008	Fieldware Tools	3.01
98-50009	RMS, Mapper	1.00c
98-50040	Software, Case AIM Navigation	2.00
98-50041	Software Valmont V-Map	2.10C
98-50046	Software, AIM Navigation	3.01
98-50047	Software, Fieldware Suite	3.00

PART # Nav Products Cont'd

SOFTWARE

78-50058	Lightbar, Swath XL	3.01
78-50075	Lightbar, Guideline	3.01
75-30002	Smartpad, Mid-Tech	3.01
75-30003	Smartpad, TeeJet	3.01
75-30005	Smartpad, II	4.09
78-50094	Remote, Wireless, CenterLine (418 Mhz)	1.00
78-50095	Lightbar CenterLine, Mid-Tech (418 Mhz)	1.02
78-50096	Lightbar CenterLine, TeeJet (418 Mhz)	1.02
78-50097	Lightbar CenterLine, LH Agro (418 Mhz)	1.02
78-50107	Remote, Wireless, CenterLine (433 Mhz)	1.00
78-50111	Lightbar, Centerline,TeeJet (433 Mhz)	2.03
98-50056	Software CenterLine	2.03
98-50055	Software Factory Install Trimble	2.10
98-50058	Software Factory Install CAN Base	2.01
98-50059	Software Module MG (Manual Guidance)	2.01
98-50060	Software Module MP (Multiple Product)	2.01
98-50061	Software Module MV (Multiple Product Variable)	2.01
98-50062	Software Module FP (Fieldpilot)	2.01
98-50063	Software Module UU (User Update)	2.01
98-50064	Software RMS	2.00
98-50065	Software RMS Office EXT	3.11
98-50112	Software RMS Office CAN Based	3.12
98-50066	Software Factory Install SA	2.03
98-50067	Software Module MG (Manual Guidance)	2.03
98-50068	Software Module MP (Multiple Product)	2.03
98-50069	Software Module MV (Multiple Product Variable)	2.03
98-50070	Software Module FP (Fieldpilot)	2.03
98-50071	Software Module UU (User Update)	2.03
98-50072	Software PCM L6K	2.13
98-50073	Software PSM L6K	2.13
98-50074	Software SSM L6K	2.13
98-50081	Software MTFW Factory Install	2.13
98-50082	Software MTFW MG Module	2.13
98-50083	Software MTFW MP Module	2.13
98-50084	Software MTFW MV Module	2.13
98-50085	Software MTFW FP Module	2.13
98-50086	Software MTFW UU User Update	2.13
98-50087	Software Fieldware for SPII	4.09
75-30021	CenterLine 220, US	1.01
75-30022	CenterLine 220, LH Agro	1.01
75-30023	CenterLine 220, Metric	1.01
75-30024	CenterLine 220, Autonomous Metric	1.01
75-30029	Centerline 220 Rev.1 Starguide	2.02
75-30031	Centerline 220 Rev.1 US	2.02
75-30032	Centerline 220 Rev.1 LH Agro	2.02
75-30033	Centerline 220 Rev.1 Metric	2.02
75-30034	Centerline 220 Rev.1 Autonomous Metric	2.02
75-30035	Centerline 220 Rev.1 Wyle	2.02

<u>PART #</u>	<u>ISM PRODUCTS</u>	<u>SOFTWARE</u>
45-06601	Cable ISM 30 Boom IS GSO	1.02
45-06602	Cable ISM 10 Boom IS GSO	1.02
45-07602	Cable ISM 10 Boom IS GSO	1.02

<u>PART #</u>	<u>CAN SWITCHBOXES</u>	<u>SOFTWARE</u>
78-30000	Switchbox Product Control 1-8 Old CAN Tee	1.03
78-30001	Switchbox Boom 1-10 old CAN Tee	1.05
78-30002	Switchbox Booms 11-20 Old CAN Tee	1.03
78-30003	Switchbox Product Control 1-8 New CAN Tee	1.03
78-30004	Switchbox Boom 1-10 New CAN Tee	1.05
78-30005	Switchbox Booms 11-20 New CAN Tee	1.03
78-30006	Switchbox, Product 1-4, Old CAN Tee	1.01
78-30007	Switchbox Boom 1-5, Old CAN Tee	1.01
78-30008	Switchbox, Product 1-4, New CAN Tee	1.01
78-30009	Switchbox Boom 1-5, New CAN Tee	1.01

98-50102	Software CAN Switchbox Booms 1-10	1.05
98-50103	Software CAN Switchbox Booms 11-20	1.03
98-50104	Software CAN Switchbox Product Control 1-8	1.03
98-50105	Software, Product Switchbox 1-4	1.01
98-50106	Software, Boom Switchbox 1-5	1.01

<u>PART #</u>	<u>SFM PRODUCTS</u>	<u>SOFTWARE</u>
78-08026	SFM 10 output series 1 CAN Old CAN Tee	1.06
78-08027	SFM 10 output WP CAN New CAN Tee	1.06
78-08034	SFM Booms 11-20 Series 1 CAN Old CAN Tee	1.07
78-08035	SFM Booms 11-20 WP CAN New CAN Tee	1.07

98-50088	Software, SFM, 1-10 Booms	1.06
98-50115	Software, SFM, 11-20 Booms	1.07

<u>PART #</u>	<u>FIELDPILOT PRODUCTS</u>	<u>SOFTWARE</u>
45-06600	Interface Switch Module, Fieldpilot input	1.01
98-50116	Software, Fieldpilot Switch Module	1.01

PART # 70 SERIES PRODUCTS (ENGLISH) **SOFTWARE**

75-30010	Console 71 Speed Area	1.13
75-30011	Console Pump Control Manual, 73 Series	1.16
75-30012	Console Fill Flow	1.04

90-02255	Kit, Speed Area	1.12
90-02259	Kit, Fill Flow, 16D F.M. 71 Series Monitor	1.03
90-02260	Kit, Fill Flow, 20D F.M. 71 Series Monitor	1.03
90-02288	Kit, Fill Flow, 801 F.M. 71 Series Monitor	1.03
90-02301	Kit, Fill Flow, 40D F.M, 71 Series Monitor	1.03
90-02302	Kit, Fill Flow 10D F.M., 71 Series Monitor	1.03
90-02263	Kit, Manual Pump, 73 Series	1.16
90-02303	Kit, Flow Volume, w/o Flowmeter	1.02

98-50092	Software Speed Area	1.13
98-50093	Software Manual Pump	1.16
98-50094	Software Fill Flow	1.03
98-50095	Software Flow Volume	1.02

PART # 70 SERIES PRODUCTS (METRIC) **SOFTWARE**

75-30015	Console, RPM Monitor	1.10
75-30016	Console, Speed Area Monitor	1.12
75-30017	Console, Manual Pump, Metric	1.16
75-30018	Console Fill Flow, Metric	1.03
75-30019	Console, Flow Volume	1.02

90-02320	Kit, Speed Area, Metric	1.12
90-02321	Kit, Fill Flow, 16D F.M. 71 Series Monitor, Metric	1.03
90-02322	Kit, Fill Flow, 20D F.M. 71 Series Monitor, Metric	1.03
90-02323	Kit, Fill Flow, 801 F.M. 71 Series Monitor, Metric	1.03
90-02324	Kit, Fill Flow, 40D F.M, 71 Series Monitor, Metric	1.03
90-02325	Kit, Fill Flow 10D F.M., 71 Series Monitor, Metric	1.03
90-02326	Kit, Flow Volume Metric, w/o Flowmeter	1.02
90-02327	Kit, Manual Pump, Metric	1.16
90-02328	Kit, RPM	1.10

98-50096	Software, RPM, Metric	1.10
98-50097	Software, Speed Area, Metric	1.12
98-50098	Software, Manual Pump, Metric	1.16
98-50099	Software, Fill Flow, Metric	1.03
98-50100	Software, Flow Volume, Metric	1.02

78-08065	Swath Manager 5	1.01
78-08045	Interface, Swath Manager	1.00

98-50119	Software, Swath Manager 5	1.01
98-50120	Software, Interface Swath Manager	1.00